



White Paper

Converter and Frame Grabber - Schematic Diagrams


Content

DFG/LC4.....	3
DFG/MC4.....	4
DFG/SV1 & DFG/SV1/LP	5
DFG/SV1/PCIe & DFG/SV1/LP/PCIe	6
DFG/USB2pro.....	7




DFG/LC4

Schematic diagram






DFG/MC4 /PCIe Schematic diagram






DFG/SV1 & DFG/SV1/LP Schematic diagram






DFG/SV1/PCIe & DFG/SV1/LP/PCIe Schematic diagram





DFG/USB2pro Schematic diagram



Converter and Frame Grabber - Schematic Diagrams ►



Headquarters: The Imaging Source Europe GmbH
Sommerstrasse 36, D-28215 Bremen, Germany
Phone: +49 421 33591-0
North & South America: The Imaging Source, LLC
6926 Shannon Willow Rd, S 400, Charlotte, NC 28226, USA
Phone: +1 704-370-0110
Asia Pacific: The Imaging Source Asia Co. Ltd.
6F-1, No.230, Sec.3, Ba-De Road, Taipei City 10555, Taiwan
Phone: +886 2-2577-1228
www.theimagingsource.com

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Company reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: February 2012

Copyright © 2012 The Imaging Source Europe GmbH, sdconvfg.en_US.pdf
All rights reserved. Reprint, also in parts, only allowed with permission of

The Imaging Source Europe GmbH.

All weights and dimensions are approximate. Unless otherwise specified the lenses shown in the context of cameras are not shipped with these cameras.