




# MSER-FPD 1.00



1.	Introduction	3
2.	MSER-FPD Rev 1.00	4
2.1	FAKRA Connector .....	4
2.2	Flex Cable Connection with Stiffener on the MSER-FPD .....	5
2.3	I/O Signals of MSER-FPD .....	8
2.4	I2C I/O Expander Configuration .....	9
2.5	I/O Connector .....	10
2.6	On-board LEDs .....	11

## 1 Introduction


This document describes the function of the MSER-FPD MIPI CSI-2 serializer board which is based on the Texas Instruments MIPI-CSI-2-to-FPD-Link III serializer chip, DS90UB953-Q1. The camera-side serializer board and platform-side deserializer board enable distances of up to 15m between any TISMIPI sensor and embedded system using a coaxial cable. The connection of these components is shown below:



The document "Deserializer Design Recommendations" contains important information required to create a custom deserializer design using the TI DS90UB954-Q1 chip.

## 2 MSER-FPD Rev 1.00

The MSER-FPD board (Rev 1.00) is shown below:




### 2.1 FAKRA Connector

The manufacturer part number of the Amphenol RF FAKRA connector is 2FA1-NZSP-PCBB6. The recommended cable type is RG-174 with 50 Ohm impedance. Please contact The Imaging Source for available assembled cables.

## 2.2 Flex Cable Connection with Stiffener on the MSER-FPD

The flex cable connection with stiffener has the following pinout:



#	Name	Type	Description
1	GND	GND	Ground
2	MIPI_CH3_N	I	MIPI CSI-2 input
3	MIPI_CH3_P	I	MIPI CSI-2 input
4	GND	GND	Ground
5	MIPI_CH1_N	I	MIPI CSI-2 input
6	MIPI_CH1_P	I	MIPI CSI-2 input
7	GND	GND	Ground
8	MIPI_DCK_N	I	MIPI CSI-2 input
9	MIPI_DCK_P	I	MIPI CSI-2 input
10	GND	GND	Ground
11	MIPI_CH2_N	I	MIPI CSI-2 input
12	MIPI_CH2_P	I	MIPI CSI-2 input
13	GND	GND	Ground
14	MIPI_CH4_N	I	MIPI CSI-2 input
15	MIPI_CH4_P	I	MIPI CSI-2 input
16	GND	GND	Ground
17	CLK	O	Reference clock output
18	CAM_PWR	O	High active camera power enable signal
19	I2C_SCL	I/O	I2C serial clock
20	I2C_SDA	I/O	I2C serial data
21	RESERVED_1	I/O	Reserved pin 1
22	RESET	O	Reset sensor to default state when low
23	RESERVED_2	I/O	Reserved pin 2
24	STROBE	I	CMOS sensor strobe signal input
25	TRIGGER/FSYNC	O	Trigger signal output
26	+5V_VDD	PWR	5V ( $\pm 10\%$ ) power supply



#	Name	Type	Description
27	+5V_VDD	PWR	5V ( $\pm 10\%$ ) power supply
28	GND	GND	Ground

## 2.3 I/O Signals of MSER-FPD

The connected I/O signals on the serializer chip DS90UB953-Q1 (Texas Instruments) are listed in the following table:

Pin	Name	Dir	Description
17 (GPIO0)	STROBE	I	Strobe signal from sensor board
18 (GPIO1)	TRIGGER_SER	I	External trigger signal from serializer board
27 (GPIO2)	TRIGGER	O	Trigger signal from deserializer board
28 (GPIO3)	RESERVED1_ GPIO3	I/O	Reserved signal

Because the DS90UB953-Q1 serializer chip does not have enough free I/O-pins, an I2C I/O expander (Texas Instruments TCA7408) has been placed on the board. The following table shows which I/O signals on the flex cable connection are connected directly to the DS90UB953-Q1 and which signals are controlled by the I2C I/O expander:

pin	Name	Dir	Description	Pin at DS90UB953	Pin at I2C I/O Expander
17	CLK	O	CMOS sensor clock	CLK_OUT (19)	
18	CAM_PWR	O	Camera power enable, active high		GPIO0 (D2)
19	I2C_SCL	I/O	I2C-Bus, clock	I2C_SCL (24)	
20	I2C_SDA	I/O	I2C-Bus, data	I2C_SDA (23)	
21	RESERVED_1	I/O	Reserved	GPIO3 (28)	
22	RESET	O	CMOS sensor reset signal, active low		GPIO1 (D3)
23	RESERVED_2	I/O	Reserved		GPIO7 (A2)
24	STROBE	I	CMOS sensor strobe signal	GPIO0 (17)	
25	TRIGGER	O	CMOS sensor trigger signal	GPIO2 (27)	

All I/Os have the same I/O voltage of 1.8V.




## 2.4 I2C I/O Expander Configuration

The I/O expander TCA7408 has the 7-bit I2C-Address 0x20. The table below shows which signals can be controlled using this expander:

I/O Pin	Name	Dir	Description
GPIO0	CAM_PWR	O	Enable CMOS sensor power supply 0: Sensor power disabled 1: Sensor power enabled
GPIO1	RESET	O	CMOS sensor reset signal 0: Sensor is in reset state 1: Sensor is in operational state
GPIO2	GPOUT_LEVEL	O	GPOUT (PicoBlade) output level selection IF GPOUT_PUSHPULL = 0 (open-drain mode): --->0: GPOUT is connected to GND --->1: GPOUT high impedent IF GPOUT_PUSHPULL = 1 (TTL/push-pull mode): --->0: GPOUT has a low level --->1: GPOUT has a high level
GPIO3	GPOUT_PUSHPULL	O	GPOUT (PicoBlade) type selection 0: GPOUT is configured as open-drain-output 1: GPOUT is configured as TTL/push-pull-output
GPIO4	LED1	O	Controls on-board LED1 0: LED1 off 1: LED1 on
GPIO5	TRIGGER_LEVEL	O	Controls the polarity of the trigger input on the PicoBlade connector. 0: Trigger source level polarity is not inverted 1: Trigger source level polarity is inverted
GPIO6	TRIGGER_SOURCE	O	Controls the source of the trigger signal that is forwarded to the sensor. 0: Sensor is triggered by the trigger signal coming from the FPD-Link / deserializer board 1: Sensor is triggered by the trigger signal that is applied to the PicoBlade I/O connector
GPIO7	RESERVED_2	O	Reserved

## 2.5 I/O Connector

The serializer also has a user GPIO connector with the following pinout:



Pin	Name	Description
1	TRIGGER_IN_P	Opto-decoupled trigger input, anode of IR-LED
2	TRIGGER_IN_N	Opto-decoupled trigger input, cathode of IR-LED
3	GP_OUT	General purpose output, referenced to GND
4	GND	System ground

The user GPIO connector is a Molex PicoBlade connector 53047-0410. The mating part for cable assembly is 510210400.

The trigger input is opto-decoupled. To drive the trigger input, a voltage must be applied to pins 1 and 2. Note: pin 1 is the positive input; pin 2 is the negative input.

Pin 3 is a general-purpose output pin that can be controlled via software. The pin can be configured for TTL mode output or open drain output. LED2 indicates a possible overcurrent.

The recommended operating conditions of the user GPIO connector J3 are displayed in the following tables. CAUTION: Functional operation beyond the recommended operating conditions is not assumed.

Parameter	Min	Max
Trigger input voltage	3.3V $\pm$ 5%	24V $\pm$ 5%

Parameter	Min	Max
TTL-mode high voltage	-	250mA @ 4V
TTL-mode low voltage	-	250mA @ 0.05V

Parameter	Min	Max
Open-drain-mode voltage	-	24V
Open-drain-mode current	-	250mA

Please make sure that enough additional power is provided via the embedded system to operate the connected devices at the user GPIO connector (J3).

## 2.6 On-board LEDs

There are two, status LEDs on the serializer board:

Name	Color	Description
LED1	Green	Controlled through GPIO4 pin on the I/O expander
LED2	Red	Indicates overcurrent flowing out of GP_OUT in TTL/push-pull mode.



## MSER-FPD 1.00

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source Europe GmbH does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Europe GmbH reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: January 2021

© 2021 The Imaging Source Europe GmbH

All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of the publisher, except in the case of brief quotations embodied in critical reviews and certain other noncommercial uses permitted by copyright law.

All weights and dimensions are approximate. Unless otherwise specified, the lenses shown in the context of cameras are not shipped with these cameras.

### Headquarters:

*The Imaging Source Europe GmbH  
Überseetor 18, D-28217 Bremen, Germany  
Phone: +49 421 33591-0*

### North & South America:

*The Imaging Source, LLC  
6926 Shannon Willow Rd, S 400, Charlotte, NC 28226, USA  
Phone: +1 704-370-0110*

### Asia Pacific:

*The Imaging Source Asia Co., Ltd.  
2F., No.8, Xinhua 1st Road  
Taipei City 114, Neihu District, Taiwan  
Phone: +886 2-2792-3153*

[www.theimagingsource.com](http://www.theimagingsource.com)