

# DFM 36MX297-ML Technical Reference Manual



## **Table of Contents**



1.	Quick Facts	3
<b>2.</b> 2.1	Electrical Characteristics  1 Absolute Maximum Ratings	<b>5</b> 5
2.2	Recommended Operating Conditions	5
<b>3.</b> 3.1	Dimensional Diagrams DFM 36MX297-ML Board Camera	6 6
<b>4.</b> 4.1	Spectral Characteristics Spectral Sensitivity - IMX297LQR-C	7
5.	Connector Description	8
6.	CSI Lane Configurations	11
7.	I2C Devices	12
8.	Programming the Image Sensor	13
8.1	1 Input Clock	13
8.2	• •	
8.3	Further Assistance	13
9.	Trigger Control FPGA	14



## 1 Quick Facts

General	
Dynamic Range	10 bit
Resolution	720x540
Frame Rate at Full Resolution	120
Pixel Formats	10-Bit Bayer (RG)

Optical Interface				
Sensor Type	Sony IMX297LQR-C			
Shutter Type	Global			
Sensor Format	1/2.9 inch			
Pixel Size	6.9 µm			

Electrical Interface				
Interface	The Imaging Source MIPI CSI-2 Sensor Board Connector			
Number of active CSI lanes	1			
Supply voltage	5V (±10%)			
Current consumption	approx 185 mA @ 5 VDC			

Mechanical Data				
Dimensions	H: 30 mm, W: 30 mm, L: 5.45 mm			
Mass	4 g			

Adjustments	
Shutter	1 μs to 1 s
Gain	0 dB to 48 dB



Environmental				
Temperature (operating)	-5 °C to 45 °C			
Temperature (storage)	-20 °C to 60 °C			
Humidity (operating)	20 % to 80 % (non-condensing)			
Humidity (storage)	20 % to 95 % (non-condensing)			

 $<sup>\</sup>mbox{\ensuremath{^{*}}}\xspace\ensuremath{\mbox{\ensuremath{)}}}\xspace$  See section Temperature Measurement Point for details.



#### **2** Electrical Characteristics

## 2.1 Absolute Maximum Ratings

Item	Symbol	Pins	Min	Max	Unit
Supply voltage	V_IN	+5V_VDD	-0.3	+6.0	V
I/O voltage	V_IO	CAM_PWR RESET CLK STROBE TRIGGER	-0.3	+2.1	V
I2C voltage	V_I2C	I2C_SCL I2C_SDA	-0.3	+2.1	V


## 2.2 Recommended Operating Conditions

Item	Symbol	Pins	Min	Тур	Max	Unit
Supply voltage	V_IN	+5V_VDD	4.5	5.0	5.5	V
I/O voltage	V_IO	CAM_PWR RESET CLK STROBE TRIGGER	1.7	1.8	1.9	V
I2C voltage	V_I2C	I2C_SCL I2C_SDA	1.7	1.8	1.9	V



## 3 Dimensional Diagrams


#### 3.1 DFM 36MX297-ML Board Camera





## 4 Spectral Characteristics


## 4.1 Spectral Sensitivity - IMX297LQR-C





## **5** Connector Description

The DFM 36MX297-ML sensor board is connected to the system via the *The Imaging Source MIPI CSI-2 Sensor Board Connector*.



# **Connector Description**



#	Name	Туре	Description	
1	GND	GND	Ground	
2	-	NC		
3	-	NC		
4	GND	GND	Ground	
5	MIPI_CH1_N	0	MIPI CSI-2 output	
6	MIPI_CH1_P	0	MIPI CSI-2 output	
7	GND	GND	Ground	
8	MIPI_DCK_N	0	MIPI CSI-2 clock	
9	MIPI_DCK_P	0	MIPI CSI-2 clock	
10	GND	GND	Ground	
11	-	NC		
12	-	NC		
13	GND	GND	Ground	
14	-	NC		
15	-	NC		
16	GND	GND	Ground	
17	CLK	I	Reference clock input (with 1k pull-down/termination resistor on sensor board)	
18	CAM_PWR	I	High active camera power enable signal (10k pull-down on sensor board)	
19	I2C_SCL	I/O	I2C serial clock	
20	I2C_SDA	I/O	I2C serial data	
21	RESERVED_1	1	Do not use	
22	RESET	I	Reset sensor to default state when low (2.2k pull-down on sensor board)	
23	RESERVED_2	1	Do not use	
24	STROBE	0	Strobe output	
25	TRIGGER	I	Trigger input (weak pulldown on sensor board)	
26	+5V_VDD	PWR	5V (±10%) power supply	
27	+5V_VDD	PWR	5V (±10%) power supply	
28	GND	GND	Ground	

# **Connector Description**



All I/Os have the same I/O voltage of 1.8V. The manufacturer part number of the Hirose connector is FH28D-28S-0.5SH(98).

# **CSI Lane Configurations**



## **6** CSI Lane Configurations

The following table shows the relationship between used CSI lanes and maximum frame rate:

No of CSI Lanes	Bits Per Pixel	<b>Maximum Frame Rate at Full Resolution</b>
1	10	120



### 7 I2C Devices

There are multiple I2C devices on the DFM 36MX297-ML sensor board. The following table describes the parts and their I2C addresses:

Address (7-bit)	Device	Description
0x1A	IMX297LQR-C	Image Sensor
0x40 (*)	LCMXO3L-1300E	Trigger Control FPGA (configuration)
0x42 (*)	LCMXO3L-1300E	Trigger Control FPGA (control)
0x50	AT24C256C	EEPROM
0x57	AT24C02C	EEPROM

<sup>(\*)</sup> Only present on sensor board revision 2.00 or later.



#### 8 Programming the Image Sensor

The data sheet for the IMX297LQR-C image sensor is not publicly available.

#### 8.1 Input Clock

The CLK pin has to be connected to a clock source. The following table lists the ranges of clock frequencies that are supported by the image sensor:

Minimum	Typical	Maximum	Unit
35.64	37.125	37.867	MHz
51.84	54	55.08	MHz
71.28	74.25	75.735	MHz

The driver provided by The Imaging Source assumes a CLK frequency of **37 MHz**. For quick integration with existing software, using this frequency is recommended.

#### 8.2 Power-up Sequence

Delay	Action
-	Set RESET to Hi-Z
-	Set CAM_PWR to Hi-Z
-	Supply 5V to 5V_VDD
-	Supply sensor clock to CLK
1 µs	Set CAM_PWR to high
20 μs	Set RESET to high
11 ms	Write sensor registers

#### 8.3 Further Assistance

For more detailed information, register settings and assistance integrating the sensor board into your product, please contact The Imaging Source support.

# **Trigger Control FPGA**



## 9 Trigger Control FPGA

In order to handle complex trigger/strobe functions of the image sensor, a FPGA is present on sensor board revision 2.00 and above.

A reference driver implementation is available upon request.



#### **DFM 36MX297-ML**

All product and company names in this document may be trademarks and tradenames of their respective owners and are hereby acknowledged.

The Imaging Source Europe GmbH cannot and does not take any responsibility or liability for any information contained in this document. The source code presented in this document is exclusively used for didactic purposes. The Imaging Source does not assume any kind of warranty expressed or implied, resulting from the use of the content of this document or the source code.

The Imaging Source Company reserves the right to make changes in specifications, function or design at any time and without prior notice.

Last update: November 2023

© 2023 The Imaging Source Europe GmbH

All rights reserved. Reprint, also in parts, only allowed with permission of The Imaging Source Europe GmbH.

All weights and dimensions are approximate. Unless otherwise specified, the lenses shown in the context of cameras are not shipped with these cameras.

#### **Headquarters:**

The Imaging Source Europe GmbH Überseetor 18, D-28217 Bremen, Germany Phone: +49 421 33591-0

#### North & South America:

The Imaging Source, LLC Suite 470, 4600 Park Road, Charlotte, NC 28209, United States Phone: +1 877-462-4772

#### **Asia Pacific:**

The Imaging Source Asia Co., Ltd. 3F., No. 43-7/8, Zhongxing Road Xizhi District, New Taipei City 221012, Taiwan

Phone: +886 2-2792-3153 www.theimagingsource.com